

TRACK CHART & SIDINGS		SIDING LENGTH	SIDING SWITCH LOCATIONS	STATION SIGN	STATIONS	METHOD OF OPERATION	DEFECT DETECTORS	RADIO CHANNELS CALL INS
				55.6	TAPPAN 17.4	CTC	48.6	(28 28) RTC 5-0
				38.2	RICHMOND 5.7	TWC		
		10,002	34.5 32.5	32.5	HAVEN 10.2	CTC	25.6	(28 28) RTC 5-4 Diesel Doctor 6-1-1
				22.3	MOUNT CLEMENS 5.8	TWC		
				16.5	FRASER 6.5			
				10.0	NOLAN 3.0		(28 28) RTC 5-1 Diesel Doctor 6-1-1	
				7.0	FOREST LAWN 1.2			
				5.8	EAST YARD 0.8	Rule 520	End to End (32 32)	
				5.0	BOC YARD 0.4			
				4.6	MILWAUKEE JCT.			

MPH
MAXIMUM SPEED **49**

MPH
SPEED RESTRICTIONS
 MP 8.1 to MP 7 - Southward Service Track (SWD movements only) (Note A) . . .20
 MP 10 to MP 4.6 - Northward and Southward Service Tracks25

MPH
SIDING SPEEDS
 Haven15

OPERATING CHARACTERISTICS

DOB LIMITS -

- Detroit Terminal DOB Flint Sub between MP 332.4 and MP 329
- Mount Clemens Sub between MP 14 and MP 4.6
- Holly Sub between MP 4.1 and MP 40
- Shore Line Sub between MP 54.8 and MP 31.2
- Flat Rock Sub between MP 2.8 and MP 39.8
- Dearborn Sub between MP 13.6 and MP 0.1

TWC - in effect between

MP 55.5 and MP 10

SIGNAL RULES - in effect

Rules 817-832

CTC - in effect between

MP 34.5 and MP 32.5TD-2

Controlled by

RAILROAD CROSSINGS AT GRADE

Controlled by

Forest Lawn CR Crossing Automatic
 Milwaukee Jct. Holly & Shore Line Sub Crossings . . CR Train Dispatcher
 CR Dispatcher Channel (64 64) DTMF 5# or (856) 231-2326



On-Track Safety	Forest Lawn
Foul Time	
Track & Time	
Planned Work	
Watchman/Lookout	X
Lone Worker	X
Lock-out Boxes	
Signal Maintainer	X
Inaccessible Track	

BULLETIN BOARDS

East YardYard Office
 Port HuronYard Office

SPRING SWITCH LOCATIONS

Normal Position

Nolan - MP 10Southward Service Track

MEASURED MILES - between

MP 46 and MP 45
 MP 16 and MP 15

SPECIAL CONDITIONS

Tappan - Northward trains exceeding 6000 feet must contact TD-3 to ensure train will not be held at Tappan.

East Yard – Due to close clearances, employees requiring blue signal protection must also provide that protection on both tracks adjacent to the track where work is to be performed. This does not apply on Tracks 6, 7, 8, and 9, and on Track 1 on the side adjacent to the Northward Service Track.

BOC Yard - Contact BOC Yardmaster before using the Northward and Southward Service Tracks between MP 10 and MP 4.6.

LOCATIONS NOT SHOWN AS STATIONS

NAME	LOCATION	LENGTH	CONNECTION
Stock Building Supplies25.21400South
B & D Drywall24.0IndustrySouth