



NORTHWARD TRAINS				ARBORFIELD SUBDIVISION				SOUTHWARD TRAINS			
	TRAIN DISPATCHER STANDBY CHANNELS AND TONES	MILES FROM CRANE	YARD LIMITS	STATIONS				OFFICE SIGNALS	SIDING CAPACITY IN FEET		
				CRANE ..... PRY							
				JCT. WITH TISDALE SUB. 14.3							
				ZENON PARK ..... 5.1							
CH 3 T 1		0.0	18.8 ↑	ARBORFIELD ..... YZ							
		14.3									
		19.4									
RULES 41 AND 44 APPLICABLE											

## ARBORFIELD SUBDIVISION FOOTNOTES

### 1 UNIFORM CODE OF OPERATING RULES

#### 1.1 TRAIN REGISTERS

**Crane**—Only trains instructed by train order will register.

### 2 GENERAL FOOTNOTES

#### 2.1 Regulations for the Protection of Track Units and Maintenance Work.

Sections 10.0 and 11.0 applicable between:  
Crane and Arborfield.

### 3 EQUIPMENT RESTRICTIONS

Unless authorization received from Office of General Superintendent Transportation, the following will apply:

3.1 Units in series 2000-3240, 4900-6900, 9300-9317 and 9400-9667 prohibited.

3.2 Heaviest car permitted (including contents):  
220,000 lbs.

### 4 SPEEDS

#### 4.1 Mileage

0.0 to 19.4 Zone

**MILES  
PER HOUR  
All Trains**  
25

### 5 SPURS AND OTHER TRACKS

5.1	NAME	Capacity		Points Face
		Mileage	In Feet	
	New Osgoode AR 02 ....	8.2	800	North
	Parkland Alfalfa AR 04 ..	12.1	1350	North & South
	Zenon Park AR 06 .....	14.3	1500	North & South
	Zenon Park AR 07 .....	.....	1200	North & South
	Arborfield AR 10 .....	19.4	1950	North & South
	Arborfield AR 11 .....	.....	1750	North & South

### EQUATED TONNAGE RATINGS—SINGLE UNIT

Car Factor	NORTHWARD		BETWEEN	SOUTHWARD		Car Factor
	1000-1076	1200-1399 1900-1917		1200-1399 1900-1917	1000-1076	
10	4320	5450	Crane and Arborfield	2740	2160	10