

BOLNEY SUBDIVISION FOOTNOTES

1 UNIFORM CODE OF OPERATING RULES

- 1.1 SPECIAL INSTRUCTIONS
System 2.0—Between mile-
age 0.9 and mileage 14.0.

2 EQUIPMENT RESTRICTIONS

Unless authorization received from Office of General Superintendent Transportation, the following will apply:

- 2.1 Only units in series 1000-1076 permitted.
- 2.2 Heaviest car permitted (including contents):
177,000 lbs.

WESTWARD TRAINS	TRAIN DISPATCHER STANDBY CHANNELS AND TONES	MILES FROM SPRUCE LAKE JCT.	YARD LIMITS	BOLNEY SUBDIVISION		OFFICE SIGNALS	SIDING CAPACITY IN FEET	EASTWARD TRAINS
				STATIONS				
↕	CH3	0.0	↓	SPRUCE LAKE JCT. YZ				↑
	T2	15.4	↑	MBS } JCT. WITH TURTLEFORD SUB. 15.4	Z			
RULES 41 AND 44 APPLICABLE RULES 321 TO 323 APPLICABLE BETWEEN MILEAGE 0.9 AND MILEAGE 14.0								

3 SPEEDS

- 3.1 Mileage
0.0 to 15.4 Zone

MILES
PER HOUR
All Trains
30

EQUATED TONNAGE RATINGS—SINGLE UNIT:

Eastward	1320 (7)
Westward	1590 (7)