

WESTWARD TRAINS	TRAIN DISPATCHER STANDBY CHANNELS AND TONES	MTC OF WAY LINE-UP CHANNELS	MILEAGE	YARD LIMITS	RHEIN SUBDIVISION		OFFICE SIGNALS	SIDING CAPACITY IN FEET	EASTWARD TRAINS
					STATIONS				
↕	CH 3 T 2	20	37.8	MBS	WROXTON Y			1430	↕
			29.9		JCT. WITH TONKIN SUB. 7.9				
			21.9		STORNOWAY 8.0				
			13.6		RHEIN 8.3				
			0.0		HAMTON 13.6				
			0.7		ROSS JCT. PRZ JCT. WITH TOGO SUB.				
RULES 41 AND 44 APPLICABLE RULE 105A NOT APPLICABLE RULES 321 TO 323 APPLICABLE BETWEEN MILEAGE 0.7 AND WROXTON									

RHEIN SUBDIVISION FOOTNOTES

1 UNIFORM CODE OF OPERATING RULES

1.1 SPECIAL INSTRUCTIONS

System 2.0—Between Mileage 0.7 and Wroxton.

2 EQUIPMENT RESTRICTIONS

Unless authorization received from Office of General Superintendent Transportation, the following will apply:

- 2.1 Only units in series 1000-1076 permitted.
- 2.2 Heaviest car permitted (including contents):
177,000 lbs.

3 SPEEDS

3.1 Mileage

0.0 to 37.8 Zone

**MILES
PER HOUR
All Trains**

20

EQUATED TONNAGE RATINGS—SINGLE UNIT

	WESTWARD	BETWEEN	EASTWARD
10	2875	Ross Jct. and Wroxton	2875
			10